


TRADE MARK

**THE****HUSTLER****CALM EXCITEMENT WILL SEIZE YOU!**

NOW BILLIARDS APPEARS ON THE SCREEN.

**Konami®**

## 20 INCH TABLE TYPE

WIDTH 910mm

DEPTH 660mm

HEIGHT 700mm(Adjustable)

## 20 INCH UP RIGHT TYPE

WIDTH 660mm

DEPTH 610mm

HEIGHT 1750mm

(The size may be changed without notice.)


We are applying for a name  
"VIDEO HUSTLER" in Japan.**Konami®**

TRADE MARK

THE


HUSTLER

NOW BILLIARDS APPEARS ON THE SCREEN.



Konami®

1. Move a target by control lever and push a shot button. White ball goes straight to a target.
2. Put Colored balls into pockets by controlling a White ball. Three speed levels for a White Ball:  
■ Slow ■ Normal ■ Fast. The White ball will be shot at desired speed as indicated.
3. One White ball can shoot three times. (Indicated Rest ). Get three more shots after you put Colored ball (Numberless ball) into a pocket within three times.
4. Bonus after you put whole Colored balls into pockets within 6 shots for a perfect prize.  
• More points by putting more than two Colored balls into pockets by one shot.  
• One extra White ball after 10,000 points.
5. A way of score (A Rate of Colored ball x Rate of pocket x patterns x 10.)



YOU CAN PUT AN ADDITION AT YOUR OPTION AS FOLLOWS.

A commemorative medal will come out after putting 6 Colored balls in order into pockets at some pattern.

**Konami®**

11-1 YOSHIMI SAKAMACHI SHONAN TOYAMA CITY OSAMA 551 JAPAN  
TELEPHONE 06-334-0292 TELEX 3232196 KONAMI J

DISTRIBUTED BY